

Standard Sills Installation Instructions

Make sure you read and understand these instructions before beginning your installation.

Tools and Materials

- Tape measure
- Square
- Pencil
- Sandpaper
- Jigsaw or small circular saw
- Polyurethane construction adhesive
- Weatherproof paintable caulk


Always wear safety eye wear when operating power tools.



1 Measure the width of the window opening from jamb to jamb.




2 Measure the depth of the window opening in three places (each end and the center). Note the largest of these dimensions.




3 Mark the width on the top of the sill.



4 Cut the sill to the width of the opening.



5 Mark the depth (the largest dimension from step 2) on the back of the sill, starting from the lip of the sill.



6 Using a saw, rip the sill to the proper depth. Sand any rough edges.

7 Insert the sill in the window opening to make sure it fits.



8 Apply 1-inch balls of polyurethane construction adhesive 3 inches from each end and 6 inches on center of the sill area.



9 Apply a bead of caulk to the back edge of the sill.



10 Insert the sill at a slight angle making contact with the window, then pivot the sill down in place.



11 Apply a bead of caulk in the joints between the sill and the window, and the sill and the drywall. Smooth the caulk with a wet finger. Occasionally, the butt-cut ends will have voids. These voids can be filled with an all-purpose adhesive caulk.